


**PV Hybrid Inverter
SPE 6000TL HVM-G2**



044.SK0014700

Version: 1.0

Table Of Contents

1. Information on this Manual	1
1.1 Validity	1
1.2 Scope	1
1.3 Target Group	1
1.4 Safety Instructions	1
2. Product Overview	2
2.1 Product Features	2
2.2 Panel and Port Definitions	3
3. Installation Instructions	4
3.1 Accessory list	4
3.2 Points for attention	4
3.3 Battery Connection	5
3.3.1 Wiring preparation	5
3.3.2 Battery power cable connection	5
3.3.3 Lithium battery communication cable connection	6
3.4 AC Connection	7
3.4.1 Connection preparation	7
3.4.2 AC Input/GEN/Output wires Connection :	7
3.5 PV Connection	9
3.5.1 Connection preparation	9
3.5.2 PV cable Connection:	9
3.6 Communication Connection	10
3.7 Dry Contact Signal	10
3.8 CT Connection	10
3.9 Wiring system for inverter	11
4. Operation	12
4.1 Power ON/OFF	12
4.2 Display Panel Introduction	12
4.2.1 LCD Display Icons	13
4.2.2 Display Information	14
4.2.3 Operating Mode Description	18
4.3 LCD parameter setting	19
5. Parallel Installation Guide	31
5.1 Parallel accessories	31
5.2 Points of Attention for Parallel	31
5.3 Wire Connections	31
5.3.1 Single-phase parallel wire connection	31
5.3.2 Three-phase parallel wire connection	33
5.4 Parallel Example	34
5.5 Parallel setup and display	35
5.6 Example of a parallel system diagram	37

6. Fault Reference Code	38
6.1 Fault Reference Code	38
6.2 Warning Indicator	39
7. Specifications	40
7.1 AC Input Specifications	40
7.2 Inverter Mode Specifications	41
7.3 Smart Load Output Power Specification	41
7.4 AC Charge Mode Specifications.....	42
7.5 MPPT Solar Charging Mode Specifications.....	42
7.6 Grid Feeding Specification.....	43
7.7 Physical Dimension.....	43
8. Appendix	44
Appendix I. Fault information and processing	44
Appendix II Restore factory settings	46
Appendix III Battery Equalization	46
Appendix IV Routine maintenance	48
Appendix V WIFI Monitoring	48

1. Information on this Manual

1.1 Validity

This manual is valid for the following devices:

- ▶ SPE 6000TL HVM-G2

1.2 Scope

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installations and operations.

1.3 Target Group

This document is intended for qualified persons and end users. Tasks that do not require any particular qualification can also be performed by end users. Qualified persons must have the following skills:

- ▶ Knowledge of how an inverter works and is operated.
- ▶ Training in how to deal with the dangers and risks associated with installing and using electrical devices and installations.
- ▶ Training in the installation and commissioning of electrical devices and installations.
- ▶ Knowledge of the applicable standards and directives.
- ▶ Knowledge of and compliance with this document and all safety information.


1.4 Safety Instructions

WARNING: This chapter contains important safety and operating instructions.

Read and keep this manual for future reference.

1. Before using the unit, read all instructions and cautionary marking on the unit, the batteries and all appropriate sections of this manual. The company has the right not to quality assurance, if not according to the instructions of this manual for installation and cause equipment damage.
2. All the operation and connection please professional electrical or mechanical engineer.
3. All the electrical installation must comply with the local electrical safety standards.
4. When install PV modules in the daytime, installer should cover the PV modules by opaque materials, otherwise it will be dangerous as high terminal voltage of modules in the sunshine.
5. **CAUTION-**To reduce risk of injury, charge only deep-cycle lead-acid type rechargeable batteries and lithium batteries. Other types of batteries may burst, causing personal injury and damage.
6. Please be clear which kind of battery system you want, lithium battery system or lead-acid battery system, if you choose the wrong system, energy storage system can't work normally.
7. **NEVER** charge a frozen battery.
8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
9. For optimum operation of this inverter, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter.
10. Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
11. **GROUNDING INSTRUCTIONS** -This inverter should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
12. **NEVER** cause AC output and DC input short circuited. Don't connect to mains when DC input short circuits.
13. Make sure the inverter is completely assembled, before the operation.
14. Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
15. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.

2. Product Overview




This is a multifunctional PV Hybrid inverter, integrated with a MPPT solar charge controller, a high frequency pure sine wave inverter and a UPS function module in one machine, which is perfect for off grid backup power and self-consumption applications. This inverter can work with or without batteries.

The whole system also need other devices to achieve complete running such as PV modules, generator, or utility grid. Please consult with your system integrator for other possible system architectures depending on your requirements. The WiFi / GPRS module is a plug-and-play monitoring device to be installed on the inverter. With this device, users can monitor the status of the PV system from the mobile phone or from the website anytime anywhere.

2.1 Product Features

- ▶ Built-in high-frequency sine wave inverter and MPPT solar controller;
- ▶ Independent generator port, built-in ATS;
- ▶ 2-channel MPPT, input current 16A+16A, power 4000W+4000W, realizes DC-DC boosting and maximum power tracking through BOOST, and the efficiency can reach up to 97%;
- ▶ Use full-bridge topology to realize DC-AC inverter function;
- ▶ 170-280VAC (or 90-280VAC) AC input range can be selected;
- ▶ The default output voltage is 230Vac, and 50HZ/60HZ output frequency can be selected;
- ▶ Charging current can be adjusted from 0A-100A;
- ▶ High-efficiency single-phase sine wave inverter output;
- ▶ Built-in solar controller and standby power-saving mode make the product more energy-saving and environmentally friendly;
- ▶ Three-stage mains charging mode and adjustable charging voltage and current;
- ▶ The use of high-speed and high-performance DSP control improves the response speed of the system;
- ▶ LED-LCD dual display;
- ▶ WIFI/GPRS function (optional);
- ▶ Up to 200% output impact resistance;
- ▶ Equipped with input over-voltage protection and input over-current protection;
- ▶ Output short-circuit protection, output over-voltage protection (can be set according to safety regulations when connected to the grid), output over-frequency protection (can be set according to safety regulations when connected to the grid), output over-current protection; output overload protection;
- ▶ BUS over and under voltage protection, over temperature protection and derating, fan fault detection, Relay fault detection; ISO insulation resistance detection, DCI protection; GFCI leakage current protection; NG detection;
- ▶ Parallel function (9 units in parallel);
- ▶ Grid connection function;
- ▶ Intelligent load management dual output;
- ▶ External CT anti-reflux function.

2.2 Panel and Port Definitions








Panel operation	
1. LCD display	2. Status indicator
3. Charging indicator	4. Fault indicator
5. Function buttons	6. WiFi/4G communication port
7.USB communication port	8. Dry contact
9.Fan	10. BMS communication port (support CAN/RS485)
11.RS485 communication port (for expansion)	12.Parallel communication ports
13.DIP	14.EXT CT
15.Fan	16.Power on/off switch
17.Battery input	18.COM
19.PV input	20. WiFi/4G communication port
21.AC output	22.AC input

3. Installation Instructions

3.1 Accessory list


Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items in the package:

Part List							
Item	Item Name	Num	A	B	C	D	E
A	The unit	1					
B	Communication cable	1					
C	Parallel communication cable	1					
D	User manual	1					
E	Tubular terminal	11					
F	R-type terminal	5					
G	O-type terminal	2					

3.2 Points for attention


Consider the following points before selecting where to install:
Install this inverter at eye level in order to allow the LCD display to be read at all times.

- ▶ The ambient temperature should be between 0°C and 55°C to ensure optimal operation.
- ▶ The recommended installation position is to be adhered to the wall vertically.
- ▶ Do not install in too narrow confined space and pay attention to ventilation.
- ▶ Be sure to keep other objects and surfaces as shown in the right diagram to guarantee sufficient heat dissipation and to have enough space for removing wires.



⚠ If the energy storage is installed in areas with salt damage, it will be corroded and may cause fire. Therefore, do not install it outdoors in areas with salt damage. The areas with salt damage are defined as the areas which are not 500m away from shore or will be affected by sea breezes. The areas affected by the sea breezes vary depending on meteorological conditions (e.g. typhoons, monsoons) or topographical conditions (dams, hills).


SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.



Install the unit by screwing three screws. It's recommended to use M4 or M5 screws.

Preparation for wiring

Before connecting all wiring, please take off bottom cover by removing four screws as shown below.



3.3 Battery Connection

⚠ WARNING!

All wiring must be performed by a qualified person.

- ▶ Shock Hazard: Installation must be performed with care due to high battery voltage in series.
- ▶ Always disconnect all circuit breakers before making connections to the battery power cable.
- ▶ Make sure the battery power cable positive (+) must be connected to battery positive (+) , negative (-) must be connected to battery negative (-) .
- ▶ Do not place anything between the flat part of the inverter terminal and the ring terminal. Otherwise, a short circuit may occur, resulting in overheating and fire.
- ▶ Do not apply anti-oxidant substance on the terminals before terminals are connected tightly.

3.3.1 Wiring preparation

1. For safety operation and regulation compliance, it's requested to install a separate DC breaker (over-current protector) or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, it's still requested to have DC breaker installed. Please refer to typical amperage in below table as required breaker size.

Recommended DC breaker specification of battery for a single inverter:


Model	1 unit*
SPE 6000TL HVM-G2	200A / 60VDC

2. It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable and terminal size as below.

Recommended battery cable and terminal size:

Model	Wire Size		Torque value
SPE 6000TL HVM-G2	1 * 2 AWG	33.6mm ²	2-3 Nm

O-type terminal:




3. Battery Module Selection: Choose the appropriate battery according to the actual situation.

Battery Type	Recommended specifications
Lead-acid Battery	200Ah capacity battery
Lithium Battery	200Ah capacity battery

3.3.2 Battery power cable connection

Please follow below steps to implement battery connection:

1. Assemble battery ring terminal based on recommended battery cable and terminal size.
2. Connect all battery packs as units requires.
3. Insert the ring terminal of battery cable flatly into battery connector of inverter and make sure the bolts are tightened with torque of 2Nm. Make sure polarity at both the battery and the inverter/charge is correctly connected and ring terminals are tightly screwed to the battery terminals.




3.3.3 Lithium battery communication cable connection


If used with lithium batteries, make sure to connect the BMS communication cable between the battery and the inverter. It is recommended to use lithium batteries that have been tested with our configuration.

Please follow below steps to implement BMS communication cable connection:

1. Connect one end of the battery's communication cable to the inverter's BMS communication port , which supports RS485 or CAN protocols.




2. The other end of the battery communication cable plugs into the battery communication port (RS485 or CAN)



3. The inverter BMS port pin and RS485 port pin assignment shown as below:

Pin number	BMS port	RS485 port (for expansion)
1	RS485B	RS485B
2	RS485A	RS485A
3	--	--
4	CANH	--
5	CANL	--
6	--	--
7	--	--
8	--	--



Note: The RS485 port (for expansion) is used for communication expansion and connection to external devices.

Note: In order to ensure the normal communication of lithium battery BMS, please set the battery type as "Li" in program 5, and then LCD will automatically switch to program 36 to select the communication protocol. You can Choose RS485 communication protocol which is from L01 to L50, and you can also choose CAN Communication protocol which is from L51 to L99. (About the specific protocol address of the inverter ,please consult the dealer or manufacturer to choose which communication protocol to match the BMS.)

3.4 AC Connection



WARNING!

- ▶ All wiring must be performed by a qualified personnel.
- ▶ Shock Hazard : Be sure that AC power source is disconnected before attempting to wire it to the unit.
- ▶ Always disconnect all circuit breakers before making AC input/GEN/AC output connection.
- ▶ Be sure to connect AC wires with correct polarity. If L and N wires are connected reversely, it may cause utility short-circuited when these inverters are worked in parallel operation.
- ▶ There are three terminal blocks with "AC INPUT", "GEN"and "AC OUTPUT" markings. Please do NOT mis-connect input and output connectors.
- ▶ Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check with manufacturer of air conditioner that if it's equipped with time-delay function before installation. Otherwise, this off grid solar inverter will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

3.4.1 Connection preparation

1. Before connecting to AC input power source, please install a separate AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input. Please refer to typical amperage in below table as required breaker size.

Recommended breaker specification of AC input for a single inverter:

Model	1 unit*
SPE 6000TL HVM-G2	63A/ 230VAC

2. It's very important for system safety and efficient operation to use appropriate cable for AC input connection and GEN connection. To reduce risk of injury, please use the proper recommended cable size as below.

Recommended AC wires size:

Model	Wire Size		Torque value
SPE 6000TL HVM-G2	1 * 8 AWG	8mm ²	1.2-1.6 Nm

3.4.2 AC Input/GEN/Output wires Connection :

Please follow the steps below to make AC output/AC input/GEN connections:

1. Remove the insulation covers of the seven wires.
2. Connect the PE protection line first, and then lock in the AC output line, AC input line, and GEN line in order. Corresponding polarity positions marked on the terminals.

Please refer to the following:






→Ground (yellow-green) L→LINE (brown or black) N→Neutral (blue)

- 1.First, insert AC output wires according to polarities indicated on terminal block and tighten terminal screws.


L→LINE (brown or black)


N→Neutral (blue)



Tubular terminal


2.Second, insert AC input wires according to polarities indicated on terminal block and tighten terminal screws.

-  → **Ground (yellow-green)**
L→ **LINE (brown or black)**
N→ **Neutral (blue)**




3.Last,insert GEN wires according to polarities indicated on terminal block and tighten the terminal screws.

- L**→ **LINE (brown or black)**
N→ **Neutral (blue)**



4.Make sure the inverter metal housing is grounded(Ground in the grid system).

-  → **Ground (yellow-green)**
L→ **LINE (brown or black)**
N→ **Neutral (blue)**



Precautions:

- Before performing the above operations, please ensure that your operating environment is: Non-energized environment.
 - After inserting the wire according to the polarity marked on the terminal, don't forget to check that the screw is tightened.
 - After you complete all wiring, please check again to confirm whether the corresponding wires are connected in the correct position to avoid misoperation that may cause the inverter to fail to work properly or damage your equipment.
- These details that cannot be ignored ensure a good user experience to a certain extent.

3.5 PV Connection

WARNING!

- ▶ All wiring must be performed by a qualified personnel.
- ▶ Shock Hazard: Operation with power on is strictly prohibited.
- ▶ Before connecting the PV input, be sure to turn off all circuit breakers and confirm that the machine is powered off.
- ▶ Be sure to connect PV cable with correct polarity.

3.5.1 Connection preparation

- Before connecting to PV modules, please install separately a DC circuit breaker between inverter and PV modules.

Recommended breaker specification of PV input for a single inverter:

Model	1 unit*(2 strings)	1unit (1 string)
SPE 6000TL HVM-G2	35A / 500Voc	16A / 500Voc

- It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below

Model	Wire Size		Torque value
SPE 6000TL HVM-G2	1 * 10 AWG	5 mm ²	1.2-1.6 Nm

- PV Module Selection:

When selecting proper PV modules, please be sure to consider below parameters:


- Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter. Exceeding the limit will cause damage to the inverter.
- Open circuit Voltage (Voc) of PV modules should be higher than start-up voltage. Lower than will lead to insufficient photovoltaic.

INVERTER MODEL	SPE 6000TL HVM-G2
Max. PV Array Open Circuit Voltage	500Vdc
Start-up Voltage	80Vdc
PV Array MPPT Voltage Range	60Vdc~450Vdc (Recommend 380 Vdc)
Quantity Of PV Panels	Recommend 3~9 photovoltaic panels


3.5.2 PV cable Connection:

Please follow below steps to implement PV module connection:

- Remove insulation sleeve 10 mm for positive and negative conductors.



- then connect positive pole(+)of connection cable to positive pole(+)of PV input connector, connect negative pole(-) of connection cable to negative pole(-) of PV input connector.



3.6 Communication Connection

Please use supplied communication cable to connect to inverter and PC. Follow on-screen instruction to install the monitoring software. For the detailed software operation, please check user manual of software. The monitoring software is downloadable from our website www.ginverter.com.

3.7 Dry Contact Signal

There is one dry contact(3A/250VAC) available on the rear panel. Dry contacts are used to connect generators. As shown in the table below. When the inverter meets the conditions on the left, it will perform the function on the right. It could be used to deliver signal to external device when battery voltage reaches warning level.

Unit Status	Condition		Dry contact port:	
			NC & C	NO & C
Power Off	Unit is off and no output is powered		Close	Open
Power On	Output is powered from Utility		Close	Open
	Output is powered from Battery or Solar	Program 01 set as Utility first	Battery voltage (SOC)< Low DC warning voltage(SOC)	Open
			Battery voltage(SOC) > Setting value in Program 13 or battery charging reaches floating stage	Close
		Program 01 is set as SBU or Solar first	Battery voltage (SOC)< Setting value in Program 12	Open
			Battery voltage (SOC)> Setting value in Program 13 or battery charging reaches floating stage	Close

3.8 CT Connection

CT is an optional accessory. Adding CT can turn on the anti-reflux function of the inverter. The specific installation method is as follows.


Serial number	CT specification	Recommender system	Property
1	100A-50mA / 2000:1 / 4m	Single system or 3 Pcs three-phase parallel system or 2Pcs Single phase parallel	Additional purchase
2	250A-62.5mA / 4000:1 / 10m	3-6 Pcs Single phase parallel or 6 Pcs three-phase parallel system	Additional purchase
3	500A-66.7mA / 7500:1 / 10m	6-9 Pcs Single phase parallel or 9 Pcs three-phase parallel system	Additional purchase

The specific installation method is as follows.

1. The L line passes through the CT, and the arrow on the CT indicates the current direction points to the inverter.
2. Connect the two signal wires coming out of the CT to the terminal marked EXT CT.


White line→ No. 1 Signal Terminal

Black line→ No. 2 Signal Terminal




Final Assembly

Double check that all wiring is correct. Please put bottom cover back by screwing four screws as shown below.




3.9 Wiring system for inverter



4. Operation


4.1 Power ON/OFF



After correct installation, switch on the battery switch, switch on the inverter switch, wait about 30s, inverter output.

4.2 Display Panel Introduction

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators, four function keys and a LCD display, indicating the operating status and input/output power information.




LED Indicator

LED Indicator			Messages
	Green	Solid On	Output is powered by utility in Line mode.
		Flashing	Output is powered by battery or PV in battery mode.
	Green	Solid On	Battery is fully charged.
		Flashing	Battery is charging.
	Red	Solid On	Fault occurs in the inverter.
		Flashing	Warning condition occurs in the inverter.

Function Buttons

Button	Description
ESC	To exit setting mode
UP	To go to previous selection
DOWN	To go to next selection
ENTER	To confirm the selection in setting mode or enter setting mode

4.2.1 LCD Display Icons




Icon	Description
AC Input Information	
	AC input icon
	Generator icon
①	Indicate AC input power, AC input voltage, AC input frequency, AC input current
AC BYPASS	Indicate AC power loads in bypass
PV Input Information	
	Down: PV1 input icon UP: PV2 input icon
④	Indicate PV power, PV voltage, PV current, etc
Output Information	
	Inverter icon
②	Indicate output voltage, output current, output frequency, inverter temperature
Load Information	
	Load icon
③	Indicate power of load, power percentage of load
OVERLOAD	Indicate overload happened
SHORT	Indicate short circuit happened
Battery Information	
	Indicate battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode.
⑤	Indicate battery voltage, battery percentage, battery current
SLA	Indicate SLA battery
LI	Indicate lithium battery
CHARGING SOL SOL+UTI Only SOL	Indicate charging source priority: solar first, solar and utility, or only solar
Other Information	
SOL.FIRST BAT.FIRST UTI.FIRST	Indicate output source priority: solar first, utility first, SBU mode or SUB mode
⑥	Indicate warning code or fault code
	Indicate a warning or a fault is happening
	Indicate it's during setting values
	Indicate the alarm is disabled
GRID TIE	Indicate the grid is feeding

In battery charge mode, battery icon will present Battery Charging Status		
Status	Battery voltage	LCD Display
Constant Current mode / Constant Voltage mode	<48V	4 bars will flash in turns.
	48 ~ 50V	Bottom bar will be on and the other will flash in turns.
	50 ~ 52V	Bottom two bars will be on and the other will flash in turns.
	> 52V	Bottom three bars will be on and the top bar will flash.
Floating mode. Batteries are fully charged.		4 bars will be on.

In battery discharge mode, battery icon will present Battery Capacity		
Load Percentage	Battery Voltage	LCD Display
Load >50%	< 41.2V	
	41.2~43.2V	
	43.2~45.2V	
	> 45.2V	
50%> Load > 20%	< 43.6V	
	43.6~45.6V	
	45.6~47.6V	
	> 47.6V	
Load < 20%	< 44.8V	
	44.8~46.8V	
	46.8~48.8V	
	> 48.8	

4.2.2 Display Information

The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selectable information is switched as below order: voltage, frequency, current, power, firmware version.












Setting Information (Off grid)	LCD display: Left	LCD display: Right
① AC Input voltage(grid input) ② Output voltage ③ Load percentage ④ Left: PV1 input voltage Right: PV2 input voltage ⑤ Battery voltage		
① AC Input voltage(generator input) (If the AC input is only generator input, it means that what is displayed at this time is the input voltage of the generator. The current, power and frequency displayed after turning the page are also the input parameters of the generator, which will not be explained below.) ② Output voltage ③ Load percentage ④ Left: PV1 input voltage Right: PV2 input voltage ⑤ Battery voltage		
① AC Input frequency ② Output frequency ③ Load VA power ④ PV energy sum ⑤ Battery percentage or voltage		
① AC Input current ② Output current ③ Load percentage ④ Left: PV1 input current Right: PV2 input current ⑤ Battery charging current		
① AC input power ② Output voltage ③ Load power ④ Left: PV1 input power Right: PV2 input power ⑤ Battery charging power		
① AC input VA power ② Inverter temperature ③ Load VA power ④ IIC temperature		

① Left: Today's Feed to Grid energy Right: Total Feed to Grid energy ② Output frequency ③ Left: Today's load energy Right: Total load energy ④ Left: Today's PV energy Right: Total PV energy ⑤ Left: Today's battery discharge energy Right: Total battery discharge energy ⑥ Indicate today's energy or total energy.		
Firmware version INV:156-00-606 LLC:157-00-606 COM: 158-00-606		
Time (13:54:29, May 29, 2024)		

Setting Information (on grid)	LCD display: Left	LCD display: Right
① Feed to Grid voltage ② Output voltage ③ Load percentage (Home Load+OP Load) ④ Left: PV1 input voltage Right: PV2 input voltage ⑤ Battery voltage		
① Feed to Grid frequency ② Output frequency ③ Load VA power (OP Load) ④ PV energy sum ⑤ Battery percentage or voltage		
① Feed to Grid current ② Output current ③ Load percentage (OP Load) ④ Left: PV1 input current Right: PV2 input current ⑤ Battery charging current		
① CT power ② CT active power screen ③ Load power (Home Load+OP Load) ④ Left: PV1 input power Right: PV2 input power ⑤ Battery charging power		



① Feed to Grid power ② Output voltage ③ Load power (OP Load) ④ Left: PV1 input power Right: PV2 input power ⑤ Battery charging power		
① CT power ② CT active power screen ③ Load power (Home Load+OP Load) ④ Inverter temperature ⑤ Ilc temperature		
① Feed to Grid VA power ② Inverter temperature ③ Load VA power (OP Load) ④ Ilc temperature		
① Left: Today's Feed to Grid energy Right: Total Feed to Grid energy ② Output frequency ③ Left: Today's load energy Right: Total load energy ④ Left: Today's PV energy Right: Total PV energy ⑤ Left: Today's battery discharge energy Right: Total battery discharge energy ⑥ Indicate today's energy or total energy.		
Firmware version INV:156-00-606 LLC:157-00-606 COM: 158-00-606		
Time (13:54:29, May 29, 2024)		

4.2.3 Operating Mode Description

Operation mode	Description	LCD display	
Standby mode / Power saving mode Note: *Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output. *Power saving mode: If enabled, the output of inverter will be off when connected load is pretty low or not detected.	No output is supplied by the unit but it still can charge batteries.	Charging by PV energy 	No charging 
Line Mode	The unit will provide output power from the mains. It can also charge the battery at line mode.	Charging by PV energy 	
		Charging by utility 	
		No battery connected 	
Feeds to the grid	Solar feeds to the grid or battery feeds to the grid	PV energy charges battery, PV energy provides power to the load and feeds remaining energy to the grid. 	
			
Battery Mode	The unit will provide output power from battery and PV power.	Power from battery and PV energy 	
		Power from battery only 	

4.3 LCD parameter setting

After pressing and holding ENTER button for 3 seconds, the unit will enter setting mode. Press "UP" or "DOWN" button to select setting programs. Then press "ENTER" button to confirm the selection or ESC button to exit.

Program	Description	Setting Option																																							
		Ty0: User-defined settings(default)  This shortcut setting item indicates that all of the following setting items are initial default values, and users need to change the setting items according to actual needs.																																							
		Ty1: On Grid Mode  Change the default values of the following settings as follows:																																							
		<table border="1"> <thead> <tr> <th>Program</th><th>Default</th><th>Setting Option</th></tr> </thead> <tbody> <tr><td>01</td><td>SUB</td><td>SUB</td></tr> <tr><td>03</td><td>UPS</td><td>UPS</td></tr> <tr><td>14</td><td>SNU</td><td>SNU</td></tr> <tr><td>55</td><td>BLU</td><td>BLU,LBU,LUB</td></tr> <tr><td>67</td><td>ENA</td><td>ENA, DIS</td></tr> <tr><td>68</td><td>SAF</td><td>SAF</td></tr> <tr><td>69</td><td>6KW</td><td>0--6KW</td></tr> <tr><td>71</td><td>DIS</td><td>ENA, DIS</td></tr> <tr><td>76</td><td>DIS</td><td>ENA, DIS</td></tr> <tr><td>78</td><td>0</td><td>0--6KW</td></tr> <tr><td>79</td><td>DIS</td><td>ENA, DIS</td></tr> <tr><td>80</td><td>12KW</td><td>0--12KW</td></tr> </tbody> </table>	Program	Default	Setting Option	01	SUB	SUB	03	UPS	UPS	14	SNU	SNU	55	BLU	BLU,LBU,LUB	67	ENA	ENA, DIS	68	SAF	SAF	69	6KW	0--6KW	71	DIS	ENA, DIS	76	DIS	ENA, DIS	78	0	0--6KW	79	DIS	ENA, DIS	80	12KW	0--12KW
Program	Default	Setting Option																																							
01	SUB	SUB																																							
03	UPS	UPS																																							
14	SNU	SNU																																							
55	BLU	BLU,LBU,LUB																																							
67	ENA	ENA, DIS																																							
68	SAF	SAF																																							
69	6KW	0--6KW																																							
71	DIS	ENA, DIS																																							
76	DIS	ENA, DIS																																							
78	0	0--6KW																																							
79	DIS	ENA, DIS																																							
80	12KW	0--12KW																																							
99	Quick Settings * After setting TY1, TY2, or TY3, the initial default values of some settings will be changed. Users can set them based on actual usage, which can help users quickly set the inverter settings	<p>The values of these settings represent a brief description: Solar energy can be fed into the power grid, default is the certification standard of the South African power grid, and the maximum power fed into the power grid is 6KW. The specific priorities are as follows:</p> <p>1. Load priority setting: When there is solar energy: solar energy is prioritized to supply power to the loads, and excess power is charged to the battery; when there is insufficient solar energy, solar energy and utility supply power to the loads together; when there is insufficient solar energy and no utility, the battery will discharge. When there is no solar energy, utility prioritizes supplying power to the load. When utility is not available, the battery only supplies power to the loads.</p>																																							

2.Charging priority setting:

solar energy and utility jointly charge the battery, and utility charging time is executed according to the program 75 setting time.

3. Solar priority setting:

BLU (default): Solar energy prioritizes charging the battery, excess energy is used to power the load, and finally the remaining energy is fed to the grid.
LBU: Solar energy is prioritized to power the load, excess energy is charged to the battery, and finally the remaining energy is fed to the grid.
LUB: Solar energy is prioritized to power the load, excess energy is fed to the grid, and finally there is surplus energy to charge the battery.

4. Battery energy priority:

The battery can be discharged only when there is no utility.

TY2: Zero Export Limit Mode

0000 042 099

Change the default values of the following settings as follows:

Program	Default	Setting Option
01	SUB	SUB
03	UPS	UPS
14	SNU	SNU
55	LUB	BLU,LBU,LUB
67	ENA	ENA, DIS
68	SAF	SAF
69	6KW	0--6KW
71	ENA	ENA, DIS
76	ENA	ENA, DIS
78	0	0--6KW
79	DIS	ENA, DIS
80	12KW	0--12KW

The values of these settings represent a brief description:

Solar and battery energy can be fed into the power grid, default is the certification standard of the South African power grid, and the maximum power fed into the power grid is 6KW. At the same time, the anti-backflow power is 0KW.

The specific priorities are as follows:

1. Load priority setting:

When there is solar energy: when there is sufficient solar energy, the solar energy is prioritized to supply power to the load, and then fed into the grid, and the excess is used to charge the battery; when there is insufficient photovoltaic energy, during the battery feeding time (Program 74), the solar energy and the battery supply power to the load and the grid together; when not during the battery feeding time (Program 74), the solar energy and utility supply power to the load together.

When there is no solar energy: during the battery feeding time (program 74), the battery supplies power to the load and feeds the grid; outside the battery feeding time (program 74), utility supplies power to the load.

2.Charging priority setting:

When there is solar energy, the solar energy charges the battery with excess energy after loading and feeding the grid; when there is no solar energy, utility sets the charging time according to program 75.

3. Solar priority setting:

BLU : Solar energy prioritizes charging the battery, excess energy is used to power the load, and finally the remaining energy is fed to the grid.
LBU: Solar energy is prioritized to power the load, excess energy is charged to the battery, and finally the remaining energy is fed to the grid.
LUB (default): Solar energy is prioritized to power the load, excess energy is fed to the grid, and finally there is surplus energy to charge the battery.

4. Battery energy priority:

When there is sufficient solar energy, the excess solar energy charges the battery.

When the solar energy is insufficient, the battery is allowed to discharge during the feeding period according to program 74.

TY3: Off Grid Mode

0000 043 099

Change the default values of the following settings as follows:

Program	Default	Setting Option
01	UTI	UTI,SOL,SBU, SUB
03	APL	UPS,APL
14	CSO	CSO,OSO,SNU
55	BLU	BLU,LBU,LUB
67	DIS	ENA, DIS
68	SAF	SAF
69	6KW	0--6KW
71	DIS	ENA, DIS
76	DIS	ENA, DIS
78	0	0--6KW
79	DIS	ENA, DIS
80	12KW	0--12KW

The values of these settings represent a brief description:

Grid connection is not enabled, enter off grid mode .

The specific priorities are as follows:

1. Load priority setting:

When there is utility: during the output time of program 50, utility bypasses to supply power to the load; outside the output time of utility, the battery and photovoltaic supply power to the load.

When there is no utility: battery and solar energy provide power to the load.

2. Charging priority setting:

Prioritize solar energy to charge the battery.

When there is solar energy, solar energy charges the battery.

When there is no solar energy, utility charges the battery during the program 50 grid output time and the program 49 utility charging time.

01	Output source priority: To configure load power source priority. (After program 67 are enabled, this program is fixed SUB and cannot be set.)	<div>Solar first</div> <div>OPPF SOL 001</div> <div>Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power the loads at the same time. Utility provides power to the loads only when any one condition happens: -Solar energy is not available -Battery voltage drops to either low-level warning voltage or the setting point in program 12.</div>
		<div>Utility first</div> <div>OPPF UTI 001</div> <div>Utility will provide power to the loads as first priority. Solar and battery energy will provide power to the loads only when utility power is not available.</div>
		<div>SBU priority</div> <div>OPPF SBU 001</div> <div>Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery will supply power to the loads at the same time. Utility provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting point in program 12.</div>
		<div>SUB priority(default)</div> <div>OPPF SUB 001</div> <div>Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, solar and utility will power loads at the same time. Battery provides power to the loads only when solar energy is not sufficient and there is no utility.</div>
02	Maximum charging current: set total charging current for solar and utility chargers.	<div>CHG1 50 002</div> <div>Default 50A, 0A~100A Settable (Max. charging current = utility charging current + solar charging current) (If LI is selected in Program 5, this program can't be set up)</div>
03	AC input voltage range (After program 67 are enabled, this program is fixed UPS and cannot be set.)	<div>Appliance (default)</div> <div>ACV APL 003</div> <div>If selected, acceptable AC input voltage range will be within: 90~280VAC</div>
		<div>UPS</div> <div>ACV UPS 003</div> <div>If selected, acceptable AC input voltage range will be within: 170~280VAC</div>
04	Power saving mode enable/disable	<div>Saving mode disable (default)</div> <div>SAVE DIS 004</div> <div>If disabled, no matter connected load is low or high, the on/off status of inverter output will not be effected.</div>
		<div>Saving mode enable</div> <div>SAVE ENA 004</div> <div>If enabled, the output of inverter will be off when connected load is pretty low or not detected.</div>

05

Battery type

AGM (default)—Suitable for lead-acid battery

BATT AGT 005

Items that cannot be set	19	20	21
default	56.4V	54V	42V

Items that can be set:	default	Set range	Set requirements
02	80A	0A~100A	
11	60A	0A~80A	
12	46V	44~51.2V	<13 setting value
13	54v	48~58.0V	

Flooded—Suitable for lead-acid battery or flood battery

BATT FLd 005

Items that cannot be set:	19	20	21
default	58.4V	56V	42V

Items that can be set:	default	Set range	Set requirements
02	80A	0A~100A	
11	60A	0A~80A	
12	48V	44~51.2V	<13 setting value
13	56v	48~58.0V	

Lithium (only suitable when communicated with BMS communication)

BATT LI 005

Items that cannot be set:	02	19	20
default		54V	54V

Items that can be set:	default	Set range	Set requirements
11	20A	0A~80A	
12	50%	10%~95%	<13 setting value
13	95%	15%~100%	
21	20%	5%~50%	<12 setting value

User-Defined—Suitable for lead-acid battery, battery parameters can be set manually

BATT USE 005

Items that can be set:	default	Set range	Set requirements
02	50A	0A~100A	
11	30A	0A~80A	
12	46V	44~51.2V	<13 setting value
13	54V	48~58.0V	
19	56.4V	48~58.4V	
20	54V	48~58.4V	
21	42V	40~48V	<12 setting value

		User-Defined 2 (suitable when lithium battery without BMS communication or communication protocol not matched with the inverter, battery parameters can be set manually) bAtE US2 005°																																	
		<table border="1"> <thead> <tr> <th>Items that can be set:</th><th>default</th><th>Set range</th><th>Set requirements</th></tr> </thead> <tbody> <tr> <td>02</td><td>20A</td><td>0A~100A</td><td></td></tr> <tr> <td>11</td><td>20A</td><td>0A~80A</td><td></td></tr> <tr> <td>12</td><td>48V</td><td>44~51.2V</td><td><13 setting value</td></tr> <tr> <td>13</td><td>52V</td><td>48~58.0V</td><td></td></tr> <tr> <td>19</td><td>54V</td><td>48~58.4V</td><td></td></tr> <tr> <td>20</td><td>54V</td><td>48~58.4V</td><td>Suggestion=19 setting value</td></tr> <tr> <td>21</td><td>46V</td><td>40~48V</td><td><12 setting value</td></tr> </tbody> </table>	Items that can be set:	default	Set range	Set requirements	02	20A	0A~100A		11	20A	0A~80A		12	48V	44~51.2V	<13 setting value	13	52V	48~58.0V		19	54V	48~58.4V		20	54V	48~58.4V	Suggestion=19 setting value	21	46V	40~48V	<12 setting value	
Items that can be set:	default	Set range	Set requirements																																
02	20A	0A~100A																																	
11	20A	0A~80A																																	
12	48V	44~51.2V	<13 setting value																																
13	52V	48~58.0V																																	
19	54V	48~58.4V																																	
20	54V	48~58.4V	Suggestion=19 setting value																																
21	46V	40~48V	<12 setting value																																
06	Auto restart when overload occurs	Restart disable (default) LdRS dIS 006°	Restart enable LdRS ENA 006°																																
07	Auto restart when over temperature occurs	Restart disable (default) EtRS dIS 007°	Restart enable EtRS ENA 007°																																
08	Output voltage	230V (default) OUtV 230 008°	220V OUtV 220 008°																																
		240V OUtV 240 008°	208V OUtV 208 008°																																
09	Output frequency	50Hz (default) OUtF 50 009°	60Hz OUtF 60 009°																																
11	Maximum utility & Generator charging current	ACI 30 ^A GENI 20 ^A 011° Default 30A/20A, 0A~80A Settable Note: If setting value in Program 02 is smaller than that in Program 11, the inverter will apply charging current from Program 02 for utility or generator charger																																	
12	Setting voltage point back to utility source when selecting "SBU priority" or "Solar first" in program 01	b2AC 460 ^V 012° The default value and adjustable range vary in different Battery type, please refer to program 5 for details Limit: program 21 +2V ≤ program 12 ≤ program 13 -2V Limit: program 21 +5% ≤ program 12 ≤ program 13 -5%																																	
13	Setting voltage point back to battery mode when selecting "SBU priority" or "Solar first" in program 01	AC2b 540 ^V 013° The default value and adjustable range vary in different Battery type, please refer to program 5 for details Limit: program 12 +2V ≤ program 13 Limit: program 12 +5% ≤ program 13																																	

14	Charger source priority: To configure charger source priority. (After program 67 are enabled, this program is fixed SUN and cannot be set.)	If this inverter is working in Line, Standby or Fault mode, charger source can be programmed as below:	
		Solar first CGPr SOL 014°	Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available.
		Solar and Utility (default) CGPr SOL+UTL 014°	Solar energy and utility will both charge battery.
		Only Solar CGPr only SOL 014°	Solar energy will be the only charger source no matter utility is available or not.
		If this Inverter is working in Battery mode or Power saving mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient.	
15	Alarm control	Alarm on (default) bUZZ ON 015°	Alarm off bUZZ OFF 015°
16	Backlight control	Backlight on LCdb ON 016°	Backlight off (default) LCdb OFF 016°
17	Beeps while primary source is interrupted	Alarm on (default) ALAr ON 017°	Alarm off ALAr OFF 017°
18	Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode.	Bypass disable (default) bYP dIS 018°	Bypass enable bYP ENA 018°
19	C.V. charging voltage.	CV 564 ^V 019° The default value and adjustable range vary in different Battery type, please refer to program 5 for details. program 19 ≥ program 20	
20	Floating charging voltage.	FLtV 540 ^V 020° The default value and adjustable range vary in different Battery type, please refer to program 5 for details. program 19 ≥ program 20	
21	Low DC cut-off voltage.	CUtV 420 ^V 021° The default value and adjustable range vary in different Battery type, please refer to program 5 for details Note: The low voltage alarm point is (program 21) +2V. When this value is reached, the machine reports 04. When reach Low DC cut-off voltage: 1) If battery power is only power source available, inverter will shut down. 2) If PV energy and battery power are available, inverter will charge battery without AC output. 3) If PV energy, battery power and utility are all available, inverter will transfer to line mode and provide output power to loads, and charge the battery at the same time. Limit: program 21 ≤ program 12 -2V(5%).	

23	AC output mode *This setting is only available when the inverter is in standby mode (Switch off). Note: Parallel operation can only work when battery connected	Parallel: (default) PRL L PAL 023°	L1 Phase: PRL L 3P1 023°
		L2 Phase: PRL L 3P2 023°	L3 Phase: PRL L 3P3 023°
		When the units are used in parallel with single phase or alone, please select "PAL" in program 23. It requires 3 inverters to support three-phase equipment, 1 inverter in each phase. Please select "3P1" in program 23 for the inverters connected to L1 phase, "3P2" in program 23 for the inverters connected to L2 phase and "3P3" in program 23 for the inverters connected to L3 phase.	
24	Dry control	Dry off dRY dIS 024°	Dry on dRY ENA 024°
		Dry Auto (default) dRY ATO 024°	
28	Address setting (for expansion)	Addr 1 028° Default 1, 1~255 Settable	
37	Real time setting---Year	2024 037°	range 2000~2099
38	Real time setting---Month	10N 12 038°	range 01~12
39	Real time setting---Date	dAY 13 039°	range 01~31
40	Real time setting---Hour	HOuR 13 040°	range 00~23
41	Real time setting---Minute	11N 50 041°	range 00~59
42	Real time setting---Second	SEC 50 042°	range 00~59
43	Battery equalization	Battery equalization enable EQ ENA 043°	Battery equalization disable(default) EQ dIS 043°
		If "Flooded" or "User-Defined" is selected in program 05, this program can be set up.	
44	Battery equalization voltage	EQV 58.4V 044° Default 58.4V, 48.0V~58.4V Settable	
45	Battery equalized time	11N Default 60min, 5min~900min Settable EQE 60 045°	
46	Battery equalized timeout	11N Default 120min, 5min~900min Settable EQTO 120 046°	

47	Equalization interval	dAY EQ 30 047°	Default 30days, 1 days~90 days Settable
48	Equalization activated immediately	Equalization activated immediately on EQ ON 048°	Equalization activated immediately off(default) EQ OFF 048°
		If equalization function is enabled in program 43, this program can be setup. If "On" is selected in this program, it's to activate battery equalization immediately and LCD main page will shows "EQ". If "Off" is selected, it will cancel equalization function until next activated equalization time arrives based on program 47setting. At this time, "EQ" will not be shown in LCD main page.	
49	Utility charging time (This program can only be set when program 67 are not enabled)	0000(default) Allow utility to charge the battery all day run. CHG L1N 0000 STA 049°	The start time can be set in the range: 00-23 (hour), 00-59 (min)The end time can be set in the range: 00-23 (hour), 00-59 (min)0000 defaults to 4 digits in total, the first two digits set the hour, and the last two digits set the minute.(Set the same number from start to end time, indicating that it is valid for 24 hours)For example: Sta2300-End2000, which means the allowed mains charging time range is from 23:00 to 20:00 of the next day.
		CHG L1N 0000 END 049°	
50	Utility output time (This program can only be set when program 67 are not enabled)	0000(default) Allow utility r to power the load all day run. OUP L1N 0000 STA 050°	The start time can be set in the range: 00-23 (hour), 00-59 (min)The end time can be set in the range: 00-23 (hour), 00-59 (min)0000 defaults to 4 digits in total, the first two digits set the hour, and the last two digits set the minute.(Set the same number from start to end time, indicating that it is valid for 24 hours)For example: Sta2300-End2000, which means the allowed mains charging time range is from 23:00 to 20:00 of the next day. Item 01 will only take effect if it is set to UTI.
		OUP L1N 0000 END 050°	
54	Lithium battery strong charging execution cycle time. (If program 05 is set to Li and set to ON, it means that the lithium battery is periodically forced to charge to SOC of 100%. OFF indicates that the function is not enabled)	OFF : Turn off periodic strong charging (default) FCHG OFF 054°	ON : Turn on periodic strong charging .Default 30days, 1 days~90 days Settable FCHG ON 054° FCHG 030 054°

55	Setting solar energy supply priority when selecting "SUB priority" in program 01 (Only selecting enable in program 67 and disable in program 71, program 55 can work)	Charge first (default) SGFD BLU 055 ⁰	Solar energy provides power to charge battery as first priority. Solar energy provides power to feed to grid as second priority.
		Load first SGFD LBU 055 ⁰	Solar energy provides power to the loads as first priority. Solar energy provides power to the charge battery as second priority.
		Load first SGFD LUB 055 ⁰	Solar energy provides power to the loads as first priority. Solar energy provides power to feed to grid as second priority.
56	NG relay enable setting	NG relay enable(default) NGFY ENA 056 ⁰	Grounding in inverter operation mode, ungrounded in grid operation mode
		NG relay disable NGFY DIS 056 ⁰	No grounding in any mode
57	The power grid mode allows the second AC output to remain on	Disable(default) OP2 DIS 057 ⁰	Enable OP2 ENA 057 ⁰
58	Setting of the second AC output time period	First time period 0000 001 058 ⁰	Second time period 0000 002 058 ⁰
		Third time period 0000 003 058 ⁰	
		Second AC output start time 2359 5tR 058 ⁰	Second AC output shutdown time 0000 ENd 058 ⁰
		The time setting consists of 4 digits, with the first two digits representing hours and the last two digits representing minutes. For example, Sta2300-End2059 represents the second AC output time range from 23:00 to 20:59 the next day.	
59	The cut-off battery voltage point/SOC setting for the second AC output	LOSS 480 ^v 059 ⁰ Default 48.0V, 44.0V~54.0V Settable Lithium battery mode: Default 60%, 20%~70% Settable	
60	Recovery battery voltage point/SOC setting for the second AC output	BACT 530 ^v 060 ⁰ Default 53.0V, 48.0V~58.0V Settable Lithium battery mode: Default 90%, 20%~100% Settable	
61	Setting of PV power value for the second AC output to be turned on	PUL 00 ^{kW} 061 ⁰ Default 0.0KW, 0KW~6KW Settable	
62	Menu Return Settings	Disable(default) MENU DIS 062 ⁰	Display screen page remains stuck
		Enable MENU ENA 062 ⁰	Automatically return to the main page after no human-machine interface operation within five minutes
65	Generator run time	GEN RUN tIn HOUR 04 065 ⁰	Default 00, range 01~23 The time allows Generator to work. Use 2 digits to represent the time period, setting range from 01 to 24.(eg: 02 represents the time allows Generator to run for two hours.

66	BMS Communication Loss	Enable (default) bTSE ENA 066 ⁰	If BMS Communication Loss, The inverter 04 and 20 warning Icon flashing, but enable to work for original status.
		Disable bTSE DIS 066 ⁰	If BMS Communication Loss, The inverter 04 and 20 warning Icon flashing and disable to work.(cut off the output and can't charge)
67	Feed to grid configuration	Feed to grid disable(default) FEED DIS 067 ⁰	Solar energy feed to grid disable.
		Feed to grid enable FEED ENA 067 ⁰	Solar energy feed to grid enable.
68	Set country customized Regulations *This setting is only available when the program 67 is that Feed to grid enable	South Africa(Default) FRNG SAR 068 ⁰	If selected, acceptable feed-in grid voltage range will be 195.5~253VAC. Acceptable feed-in grid frequency range will be 49.0~51.0Hz.
		Europe FRNG EUR 068 ⁰	If selected, acceptable feed-in grid voltage range will be 184~264.5VAC. Acceptable feed-in grid frequency range will be 51.5~47.5Hz.
		South America FRNG SAR 068 ⁰	If selected, acceptable feed-in grid voltage range will be 184~264.5VAC. Acceptable feed-in grid frequency range will be 57~62Hz.
		Asia FRNG ASA 068 ⁰	If selected, acceptable feed-in grid voltage range will be 195.5~253VAC. Acceptable feed-in grid frequency range will be 47.0~51.5Hz.
69	Feed grid power settings	FEED 60 ^{kW} 069 ⁰ The maximum feed grid power can be set Default 6KW, 0KW~6KW Settable	
70	battery feed current	L99 ^A 140 ^A 070 ⁰ Default 140A, 0A~150A Settable *If Program 05 is set to Li mode. The value LXXX in the lower left corner of the LCD is the maximum allowable discharge current of the lithium battery. The middle value is to set the maximum allowable discharge current value of the battery. The smaller of the two is the current limit value of the battery feed grid.	
71	battery feed enable	Feed to grid disable(default) FEED DIS 071 ⁰	battery energy feed to grid disable.
		Feed to grid enable FEED ENA 071 ⁰	battery energy feed to grid enable.
72	battery feed loss point	LOSS 460 ^v 072 ⁰ Lithium battery mode: Default 40%, 30%~90% Settable The other battery mode: Default 46.0V, 46.0V~52.0V Settable	
73	battery feed back point	BACT 540 ^v 073 ⁰ Lithium battery mode: Default 80%, 40%~100% Settable The other battery mode: Default 54.0V, 48.0V~54.0V Settable	

74	battery feed time	First time period 0800 001 074	Second time period 1200 002 074
		Third time period 1800 003 074	
		Battery feed start time 0800 5tA 074	Battery feed shutdown time 1159 ENd 074
		<p>* There are three time periods for battery feeding that can be set, which can be achieved by setting the start feeding time and the ending feeding time.</p> <p>*The time setting consists of 4 digits, with the first two digits representing hours and the last two digits representing minutes. For example, Sta2300-End2059 represents battery feeding time range from 23:00 to 20:59 the next day.</p>	
75	Grid charging time (The setting is only valid when program 67 is enabled)	First time period 2000 001 075	Second time period 0000 002 075
		Third time period 0600 003 075	
		Grid charging start time 2000 5tA 075	Grid charging shutdown time 2359 ENd 075
		<p>* There are three time periods for grid charging that can be set, which can be achieved by setting the start feeding time and the ending feeding time.</p> <p>*The time setting consists of 4 digits, with the first two digits representing hours and the last two digits representing minutes. For example, Sta2300-End2059 represents grid charging time range from 23:00 to 20:59 the next day.</p> <p>Note: When time period 1 is set to 0000, it means that charging can be done during the entire time period; charging takes priority over power feeding.</p>	
76	External CT	disable(default) EtCt d!S 076	Disable external CT Anti-backflow function
		enable EtCt ENA 076	Enable external CT Anti-backflow function
77	External CT sampling ratio	2000 EtR 077 Default 2000, 1000~9999 Settable. For example, 2000 means the sampling ratio is 1:2000	
78	Anti-backflow power (The setting is only valid when program 76 is enabled)	E I P 000 ^{kw} 078 Default 0kW, 0~6.0KW Settable	
79	Grid peak cutting	Disable(default) GrId d!S 079	Enable GrId ENA 079
80	Grid peak cutting power (The setting is only valid when program 79 is enabled)	GrId 120 ^{kw} 080 Default 12.0kW, 0~12.0kW Settable	

5. Parallel Installation Guide

Introduction

This inverter can be used in parallel with two different operation modes.

1. Parallel operation in single phase with up to 9 units.
2. Maximum 9 units work together to support 3-phase equipment. Seven units support one phase maximum.

5.1 Parallel accessories



Parallel communication cable

5.2 Points of Attention for Parallel






- Ensure that all breakers in the line on the load side are disconnected.
- Be sure the length of all battery cables is the same. Otherwise, there will be voltage difference between inverter and battery to cause parallel inverters not working.
- Be sure that all inverters will share the same battery bank. Otherwise, the inverters will transfer to fault mode.
- Each inverter in the parallel system can only be connected to a separate PV string, and it is prohibited for multiple PV ports to share the same string, and there is a risk of blowing up the inverter.
- Recommended battery capacity.


Inverter parallel numbers	2	3	4	5	6	7	8	9
Battery Capacity	400AH	600AH	800AH	1000AH	1200AH	1400AH	1600AH	1800AH

5.3 Wire Connections





5.3.1 Single-phase parallel wire connection


Parallel mode Port	Charts and descriptions
	<p>When the inverters are connected in parallel, the + wires are connected together and the - wires are connected together at the DC input . (chart below)</p> <p>DC Input left-positive, right-negative</p> <p>In the inverter parallel system, each inverter battery needs to be connected to a DC circuit breaker, single access circuit breaker specifications recommended 400 A. If you choose to access the total circuit breaker at the system end, the recommended access circuit breaker specifications 400 A * the number of parallel (eg: four inverter system access to the total circuit breaker, the recommended access circuit breaker specifications 1600A)</p>

AC Input	<p>When the inverters are connected in parallel, the N wires are connected together and the L wires are connected together at the AC input. (chart below)</p>  <p>In an inverter-parallel system, an AC circuit breaker is required to be connected to the utility for each inverter, and a single access circuit breaker size of 70A is recommended.</p>
Generator	<p>When the inverters are connected in parallel, the N wires are connected together and the L wires are connected together at the generator input (chart below).</p> 
AC Output	<p>When the inverters are connected in parallel, the N wires are connected together and the L wires are connected together at the AC output (chart below).</p>  <p>In an inverter-parallel system, an AC circuit breaker is required to be connected to the load for each inverter, and a single access circuit breaker size of 70A is recommended.</p>
PV Input	<p>Each inverter in the system is individually connected to the PV string (chart below).</p> 
Parallel communication port	<p>Please put the CAN communication DIP to on status for the first and the end inverter.</p> 
Lithium BMS communication port	<p>Make sure to connect the BMS communication cable between the battery and one inverter of the parallel system. It's recommended to connect to the master inverter of the parallel system.</p>



5.3.2 Three-phase parallel wire connection

Parallel mode Port	Charts and descriptions
DC Input left-positive, right-negative	<p>When the inverters are connected in parallel, the + wires are connected together and the - wires are connected together of the DC input (chart below).</p>  <p>In the inverter parallel system, each inverter battery needs to be connected to a DC circuit breaker, single access circuit breaker specifications recommended 400 A. If you choose to access the total circuit breaker at the system end, the recommended access circuit breaker specifications 400 A * the number of parallel (eg: four inverter system access to the total circuit breaker, the recommended access circuit breaker specifications 1600A).</p>
AC Input	<p>After the inverter is connected in parallel, at the AC input, the N wires are connected together and the L wires are connected together of each phase (chart below).</p>  <p>In an inverter-parallel system, an AC circuit breaker is required to be connected to the utility for each inverter, and a single access circuit breaker size of 70A is recommended.</p>
Generator	<p>After the inverter is connected in parallel, at the generator input, the N wires are connected together and the L wires are connected together of each phase (chart below).</p> 
AC Output	<p>After the inverter is connected in parallel, at the AC output, the N wires are connected together and the L wires are connected together of each phase (chart below).</p>  <p>In an inverter-parallel system, an AC circuit breaker is required to be connected to the utility for each load, and a single access circuit breaker size of 70A is recommended.</p>




5.4 Parallel Example

Parallel Operation in Single Phase

Single-phase parallel master and slave do not need to be set, the system automatically assigns the master and slave according to the order of start-up, the first one to start is the master, and the rest are the slaves. Be sure to confirm that the wiring is correct, the wiring is shown in the following figure, parallel less than nine wires in order to reduce.

Nine inverters in parallel:

Power Connection



Parallel Operation in Three Phase


Try to connect to the utility at the same time after three-phase parallel connection.

When setting up three-phase parallel, you need to define the master and the slave, see the 5.5 for the specific setting method. Be sure to confirm that the wiring is correct, the wiring method is shown in the table below. The following

chart is an example of (3+3+3) (4+3+2)


(3+3+3) Three inverters in one phase, three inverters in second phase and three inverters for the third phase:

Power Connection



(4+3+2) Four inverters in one phase, three inverters in second phase and two inverters for the third phase:

Power Connection



5.5 Parallel setup and display

Refer to Program 23 on Page 21

Parallel in Single Phase

Step 1: Check the following requirements before commissioning:

- Correct wire connection.
- Ensure all breakers in Line wires of load side are open and each Neutral wires of each unit are connected together.

Step 2: Turn on each unit and set "PAL" in LCD setting program 23 of each unit. And then shut down all units.

Note: It's necessary to turn off switch when setting LCD program. Otherwise, the setting can not be programmed.

Step 3: Turn on each unit.

LCD display in Master unit	LCD display in Slave unit

Note: Master and slave units are randomly defined.

Step 4: Switch on all AC breakers of Line wires in AC input. It's better to have all inverters connect to utility at the same time. If not, it will display warning 15.

LCD display in Master unit	LCD display in Slave unit

Step 5: If there is no more fault alarm, the parallel system is completely installed.

Step 6: Please switch on all breakers of Line wires in load side. This system will start to provide power to the load.

Parallel in Three Phase

Step 1: Check the following requirements before commissioning:

- Correct wire connection
- Ensure all breakers in Line wires of load side are open and each Neutral wires of each unit are connected together.

Step 2: Turn on all units and configure LCD program 23 as P1, P2 and P3 sequentially. Then shut down all units.

Note: It's necessary to turn off switch when setting LCD program. Otherwise, the setting can not be programmed.

Step 3: Turn on all units sequentially. Please turn on HOST inverter first, then turn on the rest one by one.

LCD display in L1-phase unit	LCD display in L2-phase unit	LCD display in L3-phase unit

Step 4: Switch on all AC breakers of Line wires in AC input. If AC connection is detected and three phases are matched with unit setting, they will work normally. Otherwise, they will display warning 15/16 and will not work in the line mode.

LCD display in L1-phase unit	LCD display in L2-phase unit	LCD display in L3-phase unit

Step 5: If there is no more fault alarm, the system to support 3-phase equipment is completely installed.

Step 6: Please switch on all breakers of Line wires in load side. This system will start to provide power to the load.


Note 1: If there's only one inverter in L1-phase, the LCD will show as "HST". If there is more than one inverter in L1-phase, the LCD of the HOST inverter will show as "HST", the rest of L1-phase inverters will show as "3P1".

Note 2: To avoid overload occurring, before turning on breakers in load side, it's better to have whole system in operation first.


Note 3: Transfer time for this operation exists. Power interruption may happen to critical devices, which cannot bear transfer time.

5.6 Example of a parallel system diagram

Single-phase parallel wire connection :
























Three-phase parallel wire connection :




























6. Fault Reference Code

6.1 Fault Reference Code


Fault Code	Fault Event	Icon on
02	Over temperature	02 
03	Battery voltage is too high	03 
05	Output short circuited	05 
06	Output voltage is too high.	06 
07	Overload time out	07 
08	Bus voltage is too high	08 
09	Bus soft start failed	09 
11	The main relay failed	11 
18	LLC Over current or surge	18 
50	IGBT Over current or surge	50 
51	INV Over current or surge	51 
52	Bus voltage is too low	52 
53	Inverter soft start failed	53 
58	Output voltage is too low	58 
60	Negative power fault	60 
61	PV voltage is too high	61 
62	Internal communication error	62 
65	BUS voltage imbalance	65 
66	GFCI is too high	66 
67	DCI failed	67 
80	CAN fault	80 

6.2 Warning Indicator

Warning Code	Warning Event	Audible Alarm	Icon flashing
02	Over temperature	Beep once every second	02 
03	Battery is over-charged	Beep once every second	03 
04	Low battery	Beep once every second	04 
07	Overload	Beep once every 0.5 second	07 
10	Output power derating	Beep twice every 3 seconds	10 
13	Solar charger stops due to high PV voltage	Beep once every second	13 
14	Solar charger stops due to overload	Beep once every second	14 
15	Parallel input utility grid different	Beep once every second	15 
16	Parallel input phase error	Beep once every second	16 
17	Parallel output phase loss	Beep once every second	17 
19	Battery disconnect	No beep	19 
20	BMS communication error	Beep once every second	20 
21	PV power insufficient	Beep once every second	21 
22	Parallel forbidden without battery	Beep once every second	22 
23	The parallel version is different	Beep once every second	23 
25	Parallel inverters' capacity different	Beep once every second	25 
26	ISO detection failed	Beep once every second	26 
28	GFCI error	Beep once every second	28 
36	Li battery total over voltage	Beep once every second	36 
37	Li battery total under voltage	Beep once every second	37 
38	Li battery discharge over voltage	Beep once every second	38 
39	Li battery charge over voltage	Beep once every second	39 
40	Li battery discharge over temperature	Beep once every second	40 
41	Li battery charge over temperature	Beep once every second	41 
81	Host loss	Beep once every second	81 

7. Specifications

7.1 AC Input Specifications

INVERTER MODEL	SPE 6000TL HVM-G2
Nominal Input Voltage	230Vac
Input Voltage Range	170~280Vac (UPS); 90~280Vac (APL)
Low Loss Voltage	170Vac±7V (UPS); 90Vac±7V (APL)
Low Loss Return Voltage	180Vac±7V (UPS); 100Vac±7V (APL)
High Loss Voltage	280Vac±7V
High Loss Return Voltage	270Vac±7V
Nominal Input Frequency	50Hz / 60Hz (Auto detection)
Low Loss Frequency	40±1Hz
Low Loss Return Frequency	42±1Hz
High Loss Frequency	65±1Hz
High Loss Return Frequency	63±1Hz
Overload Protection	AC Bypass: load≤110%, normal; 110%<load <150%, 07 warning load >150%: 5s AC Input Circuit > 40A: 10s
Output Short Circuit Protection	Circuit Breaker
MAX Bypass Circuit	40A±1A
Transfer Time	10ms typical, RCD 20ms Max@ Single <30ms @ Parallel
Output power derating: When AC input voltage drops to 170V, the output power will be derated.	

7.2 Inverter Mode Specifications

INVERTER MODEL	SPE 6000TL HVM-G2
Output Voltage Waveform	Pure Sine Wave
No Load Power Consumption	< 35W
Rated Output Power	6.0KVA/6.0KW
Nominal Output Current	26.1A
Output Voltage Regulation	230Vac±2%
Output Frequency	50Hz/60Hz±0.3Hz
Output Voltage THDV	Linear Load <3%, Nonlinear Load < 5%
INV Efficiency	95.5% MAX
Overload Protection	Inverter: 101%< load <150% : 10s; load >150%: 5s
Nominal DC Input Voltage	48Vdc
Cold Start Voltage(Lead-Acid Mode)	46.0Vdc
Low DC Cut-off Voltage (Lead-Acid Mode)	42.0Vdc @ load < 20% 40.8Vdc @ 20% ≤ load < 50% 38.4Vdc @ load ≥ 50%
Low DC Warning Voltage (Lead-Acid Mode)	Low DC Cut-off SOC + 2Vdc
Low DC Warning Return Voltage (Lead-Acid Mode)	Low DC Cut-off SOC + 4Vdc
Low DC Cut-off SOC (Li Mode)	20%
Cold Start SOC(Li Mode)	Low DC Cut-off SOC + 10%
Low DC Warning SOC (Li Mode)	Low DC Cut-off SOC +5%
Low DC Warning Return SOC (Li Mode)	Low DC Cut-off SOC +10%
High DC Recovery Voltage	56.4Vdc
High DC Cut-off Voltage	60.0Vdc
Transfer Time	10ms typical, RCD 20ms Max@ Single <30ms @ Parallel

7.3 Smart Load Output Power Specification

It's applicable to Hybrid & Off-Grid	
Model	SPE 6000TL HVM-G2
Full Load Output Power	6000W
Maximum Main Load	6000W
Maximum smart load	6000W

7.4 AC Charge Mode Specifications

AC Charging Mode		
INVERTER MODEL		SPE 6000TL HVM-G2
Charging Algorithm		3-Step or Equalizing Charging
Max. AC Charging Current		80A
Bulk Charging Voltage	Flooded Battery	58.4Vdc
	AGM / Gel Battery	56.4Vdc
Floating Charging Voltage		54Vdc
Charging Curve		<p>3-Step Charging</p>
		<p>Eq Charging</p>

7.5 MPPT Solar Charging Mode Specifications

MPPT Solar Charging Mode	
INVERTER MODEL	SPE 6000TL HVM-G2
Max. PV Array Power	4000W+4000W
Max. PV Input Current	16A±1A/16A±1A
Start-up Voltage	80Vdc±5Vdc
PV Array MPPT Voltage Range	60Vdc~450Vdc±5Vdc
Max. PV Array Open Circuit Voltage	500Vdc
Nominal PV Voltage	380Vdc
PV Array Voltage High Loss	510Vdc±5Vdc fault (500Vdc warning)
PV Array Voltage High Comeback	490Vdc±5Vdc
Number of MPP Trackers	2
Charging Algorithm	3-Step or Equalizing Charging

7.6 Grid Feeding Specification

Grid Feeding Mode	
Model	SPE 6000TL HVM-G2
Nominal output voltage	230Vac
Nominal output frequency	50Hz / 60Hz (Auto detection)
Max feeding power	6000W
Output voltage range	195.5~253VAC(±3%)@Asia regulation 184~264.5VAC(±3%)@Europe regulation 184~264.5VAC(±3%)@South America regulation 195.5~253VAC(±3%)@South Africa regulation (default)
Output voltage comeback value	205~243VAC(±3%)@Asia regulation 194~254.5VAC(±3%)@Europe regulation 194~254.5VAC(±3%)@South America regulation 195.5~253VAC(±3%)@South Africa regulation(default)
Operational frequency range	49-51Hz(±0.1Hz)@Asia regulation 47.5~51.5Hz(±0.1Hz)@Europe regulation 57-62Hz(±0.1Hz)@South America regulation 47.0Hz~51.5Hz(±3%)@South Africa regulation(default)
Output frequency comeback value	49.5~50.5Hz(±0.1Hz)@Asia regulation 48-51Hz(±0.1Hz)@Europe regulation 57.5~61.5Hz(±0.1Hz)@South America regulation 47~51.5Hz(±0.1Hz)@South Africa regulation(default)
Output current	26.1A
O/P current distortion	<5%
O/P current DC component	<130mA
Power Factor	0.8 leading to 0.8 lagging
Max. Conversion Efficiency(PV/AC)	96.5%
European Efficiency @Vnominal(PV/AC)	95.5%

7.7 Physical Dimension

Physical Dimension Mode	
INVERTER MODEL	SPE 6000TL HVM-G2
Inverter dimension(L*W*H),mm	457*422*115
Packaging dimension(L*W*H),mm	460*422*125
colour	White
Net Weight (KG)	13
Rough Weight (KG)	15

8. Appendix

Appendix I. Fault information and processing

The energy storage inverter is designed according to the off-grid connected operation standard and meets the safety requirements and electromagnetic compatibility requirements. Before leaving the factory, the inverter undergoes several rigorous tests to ensure that the inverter can operate reliably.



If any of the fault messages listed in Table 6-1 appear on your inverter and the fault has not been removed after restarting, please contact your local dealer or service center. You need to have the following information ready.

1. Inverter serial number;
2. The problem description (including the fault code and indicator status displayed on the LCD, or specific fault video and picture) is as detailed as possible.
3. Basic system component information (such as batteries, photovoltaic panels, load usage and specifications)
4. Your contact information.

In order to give you a clearer understanding of the inverter's fault information, we will list all possible fault codes and their descriptions when the inverter is not working properly

error code	Description	Solutions
F02	Internal temperature of component is over 100°C.	Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
F03	Battery is over-charged.	Restart the unit
	The battery voltage is too high	1.Measure battery voltage in DC input.(Check battery SOC in LCD when use Li battery) 2.Adjust the charging current to less than 0.2C 3.Check if spec and quantity of batteries are meet requirements.
W04	Battery voltage is too low	1.Measure battery voltage in DC input.(Check battery SOC in LCD when use Li battery) 2.Recharge the battery.
F05	Output short circuited	1.Disconnect load and restart the unit 2.Check if wiring is connected well and remove abnormal load.
F07	Overload time out	Reduce the connected load by switching off some equipment.
F08	Bus voltage is too high	1. If you connect to a lithium battery without communication, check whether the voltage points of the program 19 and 21 are too high for the lithium battery. 2. Restart the unit
F09/53/57	Bus soft start failed	Restart the unit
W15	The input status is different in parallel system.	Check if AC input wires of all inverters are connected well.
W16	Input phase is not correct.	Change the input phase S and T wiring.
W17	The output phase not correct in parallel.	1.Make sure the parallel setting are the same system(single or parallel; 3P1,3P2,3P3). 2.Make sure all phases inverters are power on.

W19	lead acid battery disconnect	Check if spec and quantity of batteries are meet requirements.
	Lithium battery disconnect	1. Check BMS communication cable connection 2. Check setup parameters
W20	BMS communication error	1. Check whether communication line is correct connection between inverter and battery. 2. Check whether BMS protocol type is correct setting.
F51	Over current or surge	Restart the unit
F52	Bus voltage is too low	
F55	Output voltage is unbalanced	
F61	PV voltage is too high	1. Measure whether the PV voltage in the DC input is consistent with the value displayed on the LCD screen. 2. If consistent, standardize the parallel connection method of PV panels.
F62	Internal communication error	Restart the unit
F80	CAN fault	1. Check whether the parallel communication cables are connected well. 2. Check whether Program 23 settings are right for the parallel system.
F81	Host loss	

Other Problem	LCD/LED/Buzzer	Explanation	What to do
Unit shuts down Automatically during startup process.	LCD/LEDs and buzzer will be active for 3 seconds and then complete off.	The battery voltage is too low.($<1.91V/Cell$)	1. Re-charge battery. 2. Replace battery.
No response after power on.	No indication.	1.The battery voltage is far too low. ($<1.4V/Cell$) 2.Battery polarity is connected reversed.	1. Check if batteries and the wiring are connected well. 2. Re-charge battery. 3. Replace battery.
Mains exist but the unit works in battery mode.	Input voltage is 0 on the LCD and green LED is flashing.	Input protector is tripped.	Check if AC breaker is tripped and AC wiring is connected well.
	Green LED is flashing.	Insufficient quality of AC power (Shore or Generator)	1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if input voltage range setting is correct. (UPS→Appliance)
	Green LED is flashing.	Set "Battery First" or "Solar First" as the priority of output source.	Change output source priority to Utility first.
When it's turned on, internal relay is switching on and off repeatedly.	LCD display and LEDs are flashing	Battery is disconnected.	Check if battery wires are connected well.

Note: To restart the inverter, all power sources need to be disconnected. After the LCD screen light is off, only use the battery to boot.

Appendix II Restore factory settings

After pressing and holding UP and DOWN buttons at the same time for 3 seconds, the unit will enter PASSmode. Change the middle three numbers 000 to 305. Then press "ENTER" button to confirm the selection and wait about 7 seconds. Press "ESC" to return and the setting is completed.

Note: When inverter is used in parallel, every inverter needs to disconnect parallel communication cable and restore alone.

Program	Setting Option
PASS	PASS 305 000

Appendix III Battery Equalization

43	Battery equalization	Battery equalization enable EQ ENA 043	Battery equalization disable(default) EQ DIS 043
		If "Flooded" or "User-Defined" is selected in program 05, this program can be set up.	
44	Battery equalization voltage	EQV 58.4 044 Default 58.4V, 48.0V~58.4V Settable	
45	Battery equalized time	71 0	Default 60min, 5min~900min Settable
		EQE 60 045	
46	Battery equalized timeout	71 0	Default 120min, 5min~900min Settable
		EQE0 120 046	
47	Equalization interval	30 047	Default 30days, 1 days~90 days Settable
		EQI 30 047	
48	Equalization activated immediately	EQ ON 048	Equalization activated immediately off(default)
		If equalization function is enabled in program 43, this program can be set up. If "On" is selected in this program, it's to activate battery equalization immediately and LCD main page will show "EQ". If "Off" is selected, it will cancel equalization function until next activated equalization time arrives based on program 47 setting. At this time, "EQ" will not be shown in LCD main page.	


Equalization function is added into charge controller. It reverses the buildup of negative chemical effects like stratification, a condition where acid concentration is greater at the bottom of the battery than at the top. Equalization also helps to remove sulfate crystals that might have built up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it's recommended to equalize battery periodically.

- How to Apply Equalization Function

You must enable battery equalization function in monitoring LCD setting program 43 first. Then, you may apply this function in device by either one of the following methods:


1. Setting equalization interval in program 47.
 2. Active equalization immediately in program 48.
- When to Equalize

In float stage, when the setting equalization interval (battery equalization cycle) is arrived, or equalization is active immediately, the controller will start to enter Equalize stage.




- Equalize charging time and timeout

In Equalize stage, the controller will supply power to charge battery as much as possible until battery voltage raises to battery equalization voltage. Then, constant-voltage regulation is applied to maintain battery voltage at the battery equalization voltage. The battery will remain in the Equalize stage until setting battery equalized time is arrived.



However, in Equalize stage, when battery equalized time is expired and battery voltage doesn't rise to battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves battery equalization voltage. If battery voltage is still lower than battery equalization voltage when battery equalized time setting is over, the charge controller will stop equalization and return to float stage.



Appendix IV Routine maintenance

To ensure the long-term and good operation of the energy storage system, it is recommended to perform the routine maintenance as described in this section (Cleaning and maintenance of the inverter must be carried out with the power supply disconnected to ensure personal safety).

Items	Methods	Maintenance interval
System cleanliness for inverter	Regularly check the surface of the inverter for dust or other debris and clean it with a dust sponge.	Once every six months to one year
	Regularly check that radiators and vents are not covered with dust and clean them with a soft brush or compressed air.	Once every 3 months.
Electrical connection	Check if any cable connection is off or loose.	Half a year after first debugging and testing, and once every six months to one year thereafter.
	Check if any cable is damaged, and especially if there are cuts on the sheath where the cable contacts with the metal surface.	
	Check the internal circuit boards and components of the inverter for abnormalities, such as damage, discoloration, etc., and repair and replace them in a timely manner.	
Grounding reliability	Check if the grounding cable is grounded reliably.	
normal operation	Periodically check the input voltage. output voltage and current of the inverter to ensure that it is operating within its rated range.	
	Regularly check the operating status and performance parameters of the inverter via the inverter's monitoring system or display.	
Other Maintenance	Ensure that the inverter is installed in a dry, well-ventilated environment, protected from humidity, heat or excessive dust.	

Appendix V WIFI Monitoring

Plug cube WIFI into the WIFI/4G port. Scan the QR code below to download ShinePhone,also you can search ShinePhone in iOS or Google Play Store,download and install it.

- Note: 1.Make sure you download the latest version.
- 2.For further information please visit server. growatt.com

